

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
ACURA					
CL	2003 - 1997		24"	19"	
INTEGRA	2001 - 1994		22"	18"	19"
INTEGRA	1993 - 1990		20"	19"	19"
INTEGRA	1989 - 1986		18"	18"	18"
LEGEND	1995 - 1993		22"	19"	
LEGEND	1992 - 1991		20"	19"	
MDX	2009 - 2007		26"	21"	
MDX	2006 - 2001		24"	21"	
NSX	2005 - 1991		22"	22"	
RDX	2009 - 2007		26"	16"	
RL	2004 - 1996		22"	19"	
RSX	2006 - 2002		24"	20"	20"
SLX	1999 - 1996		20"	20"	15"
TL	2009 - 2004		26"	19"	
TL	2003 - 1995		24"	19"	
TSX	2009 - 2004		26"	16"	
VIGOR	1994 - 1992		24"	19"	
ALFA ROMEO					
164	1995 - 1994		20"	20"	
164	1993 - 1991		21"	21"	
GTV-6	1986 - 1981		17"	17"	
MILANO	1989 - 1987		18"	18"	
SPIDER	1994 - 1980		16"	16"	
AUDI					
100	1994 - 1992		22"	22"	18"
100	1991 - 1989		21"	21"	
200	1991 - 1989		21"	21"	
4000	1987 - 1984		21"	21"	18"
4000	1983 - 1980		18"	18"	
5000	1988 - 1984		18"	18"	
5000	1983 - 1980		21"	21"	
80	1992 - 1988		21"	21"	
90	1995 - 1988		21"	21"	
A4	2001 - 1996		21"	21"	
A6	2004 - 1995		22"	22"	
A6	2004 - 1998	Wagon	22"	22"	18"
A8	2003 - 1997		22"	22"	
ALLROAD QUATTRO	2003 - 2001		22"	22"	
CABRIOLET	1998 - 1995		22"	22"	
CABRIOLET	1994 - 1994		21"	21"	
COUPE	1987 - 1982		21"	21"	
QUATTRO	1986 - 1984		21"	21"	18"
QUATTRO	1983 - 1983		18"	18"	18"
S4	2002 - 2002		21"	21"	
S4	2001 - 1992		22"	22"	
S6	2003 - 2002		22"	22"	18"
S6	1997 - 1995		22"	22"	
S8	2002 - 2001		22"	22"	
TT	2004 - 2000		21"	21"	
V8 QUATTRO	1994 - 1993		22"	22"	
V8 QUATTRO	1992 - 1990		21"	21"	

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
BMW					
3-SERIES	1999 - 1995	TI	21"	20"	18"
3-SERIES	1999 - 1992	Exc. Convertible	21"	20"	
3-SERIES	1999 - 1994	Convertible	22"	20"	
3-SERIES	1991 - 1984		20"	20"	
3-SERIES	1983 - 1980		18"	18"	
5-SERIES	1988 - 1982		18"	18"	
7-SERIES	1987 - 1980		18"	18"	
M3	1999 - 1995		21"	20"	
M3	1991 - 1988		20"	20"	
M5	1993 - 1991		22"	24"	
M5	1988 - 1988		18"	18"	
X3	2009 - 2004		22"	20"	
X5	2006 - 2000		24"	22"	
Z3	2002 - 1996		20"	20"	
Z4	2008 - 2003		21"	20"	
BUICK					
CENTURY	2005 - 1998		22"	22"	
CENTURY	1997 - 1997	Early Model	18"	18"	
CENTURY	1997 - 1997	Late Model	22"	22"	
CENTURY	1996 - 1980		18"	18"	
ELECTRA	1990 - 1985		19"	19"	
ELECTRA	1984 - 1980		18"	18"	
LACROSSE	2009 - 2005		22"	22"	
LESABRE	2005 - 1992		22"	22"	
LESABRE	1991 - 1987		19"	19"	
LESABRE	1986 - 1980		18"	18"	
PARK AVENUE	2005 - 1991		22"	22"	
RAINIER	2007 - 2004		22"	22"	16"
REATA	1991 - 1988		19"	19"	
REGAL	2004 - 1998		22"	22"	
REGAL	1997 - 1997		20"	20"	
REGAL	1996 - 1988	FWD	20"	20"	
REGAL	1988 - 1988	RWD	20"	20"	
REGAL	1987 - 1984	RWD	18"	18"	
RENDEZVOUS	2007 - 2002		24"	22"	16"
RIVIERA	1999 - 1995		22"	22"	
RIVIERA	1993 - 1986		19"	19"	
ROADMASTER	1996 - 1991		22"	22"	16"
SKYHAWK	1989 - 1982		16"	16"	16"
SKYLARK	1998 - 1986		19"	19"	
SKYLARK	1985 - 1980		18"	18"	
SOMERSET	1987 - 1986		19"	19"	
SOMERSET REGAL	1985 - 1985		19"	19"	
TERRAZA	2007 - 2005		24"	22"	16"
CADILLAC					
ALLANTE	1993 - 1987		19"	19"	
BROUGHAM	1992 - 1987	RWD	18"	18"	
CATERA	2001 - 1997		24"	19"	
CIMARRON	1988 - 1982		16"	16"	
COMMERCIAL CHASSIS	1984 - 1980		18"	18"	
CTS	2009 - 2008		22"	19"	

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
CTS	2007 - 2003		22"	21"	
DEVILLE	2005 - 1991		22"	22"	
DEVILLE	1990 - 1985		19"	19"	
DEVILLE	1984 - 1980		18"	18"	
DTS	2009 - 2006		22"	22"	
ELDORADO	2002 - 1992		22"	22"	
ELDORADO	1991 - 1986		19"	19"	
ELDORADO	1985 - 1980		18"	18"	
ESCALADE	2009 - 2009		22"	22"	
ESCALADE	2006 - 2002		22"	22"	
ESCALADE	2000 - 1999		18"	18"	
FLEETWOOD	1996 - 1991		22"	22"	
FLEETWOOD	1990 - 1986		19"	19"	
FLEETWOOD	1985 - 1980		18"	18"	
SEVILLE	2004 - 1992		22"	22"	
SEVILLE	1991 - 1986		19"	19"	
SEVILLE	1985 - 1985		18"	18"	
SRX	2009 - 2004		22"	21"	13"
XLR	2009 - 2004		20"	20"	
CHEVROLET					
ASTRO	2005 - 1993		18"	18"	13"
ASTRO	1992 - 1985		18"	18"	13"
AVALANCHE	2009 - 2009		22"	22"	
AVALANCHE	2006 - 2002		22"	22"	
AVEO	2009 - 2004		22"	19"	
AVEO5	2009 - 2009		22"	18"	15"
BERETTA	1996 - 1987		19"	19"	
BLAZER	2004 - 1995		20"	20"	
BLAZER	1994 - 1988		18"	18"	14"
C1500	1999 - 1988		18"	18"	
C1500 SUBURBAN	1999 - 1992		18"	18"	
C2500	2000 - 1988		18"	18"	
C2500 SUBURBAN	1999 - 1992		18"	18"	
C3500	2002 - 2001		22"	22"	
C3500	2000 - 1988		18"	18"	
CAMARO	2002 - 1997		24"	24"	
CAMARO	1993 - 1989		18"	18"	
CAMARO	1988 - 1982		18"	18"	18"
CAPRICE	1996 - 1991		22"	22"	16"
CAPRICE	1990 - 1990		18"	18"	16"
CAPRICE	1989 - 1980		18"	18"	
CAVALIER	2005 - 1995		22"	17"	
CAVALIER	1994 - 1982		16"	16"	
CELEBRITY	1990 - 1990		18"	18"	
CELEBRITY	1989 - 1984		18"	18"	16"
CHEVETTE	1987 - 1980		16"	16"	16"
CITATION	1983 - 1980		18"	18"	
CITATION II	1985 - 1984		18"	18"	
CLASSIC	2005 - 2004		22"	19"	
COBALT	2009 - 2005		22"	17"	
COLORADO	2009 - 2004		22"	19"	
CORSICA	1996 - 1987		19"	19"	

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
CORVETTE	2009 - 2005		21"	21"	
CORVETTE	2004 - 1997		22"	22"	
CORVETTE	1996 - 1984		20"	20"	
CORVETTE	1982 - 1980		16"	16"	
EL CAMINO	1987 - 1980		18"	18"	
EQUINOX	2009 - 2005		24"	19"	
EXPRESS 1500	2009 - 1999		22"	22"	
EXPRESS 2500	2009 - 1999		22"	22"	
EXPRESS 3500	2009 - 1999		22"	22"	
G10	1995 - 1993		18"	18"	
G10	1992 - 1980		16"	16"	
G20	1995 - 1993		18"	18"	
G20	1992 - 1980		16"	16"	
G30	1996 - 1996		22"	22"	
G30	1995 - 1993		18"	18"	
G30	1992 - 1980		16"	16"	
HHR	2009 - 2006		18"	18"	
IMPALA	2009 - 2006		22"	22"	
IMPALA	1985 - 1980		18"	18"	
K1500	1999 - 1988		18"	18"	
K1500 SUBURBAN	1999 - 1992		18"	18"	
K2500	2000 - 1988		18"	18"	
K2500 SUBURBAN	1999 - 1992		18"	18"	
K30	1986 - 1980		16"	16"	
K3500	2000 - 1988		18"	18"	
K5 BLAZER	1986 - 1980		16"	16"	
LUMINA	2001 - 1995	Sedan	22"	22"	
LUMINA	1994 - 1990	Sedan	20"	20"	
LUMINA APV	1996 - 1990		24"	24"	13"
MALIBU	2007 - 2004		22"	20"	
MALIBU	2003 - 1997		22"	19"	
MALIBU	1983 - 1980		18"	18"	
METRO	2001 - 1998		20"	19"	
MONTE CARLO	2007 - 2006		22"	22"	
MONTE CARLO	2005 - 1995		22"	22"	
MONTE CARLO	1988 - 1980		18"	18"	
MONZA	1980 - 1980		16"	16"	
NOVA	1988 - 1985		17"	17"	
P30	1994 - 1990		18"	18"	
PRIZM	2002 - 1998		20"	18"	
S10	2004 - 1994	Pick-up	20"	20"	
S10	1993 - 1982	Pick-up	16"	16"	
S10 BLAZER	1994 - 1991		16"	16"	13"
S10 BLAZER	1990 - 1983		16"	16"	
SILVERADO 1500	2007 - 2007	Classic	22"	22"	
SILVERADO 1500	2006 - 1999		22"	22"	
SILVERADO 1500 HD	2007 - 2007	Classic	22"	22"	
SILVERADO 1500 HD	2006 - 2001		22"	22"	
SILVERADO 2500	2004 - 1999		22"	22"	
SILVERADO 2500 HD	2007 - 2007	Classic	22"	22"	
SILVERADO 2500 HD	2006 - 2001		22"	22"	
SILVERADO 3500	2007 - 2007	Classic	22"	22"	

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
SILVERADO 3500	2006 - 2001		22"	22"	
SPECTRUM	1988 - 1985		18"	18"	15"
SPRINT	1991 - 1990		19"	18"	
SPRINT	1989 - 1989		19"	18"	15"
SPRINT	1988 - 1985		17"	17"	15"
SSR	2006 - 2003		20"	19"	
SUBURBAN	2009 - 2009		22"	22"	
SUBURBAN	2006 - 2000		22"	22"	16"
TAHOE	2009 - 2009		22"	22"	
TAHOE	2006 - 2000		22"	22"	16"
TAHOE	1999 - 1995		18"	18"	14"
TRACKER	2004 - 1998		19"	19"	15"
TRAILBLAZER	2009 - 2007		22"	22"	16"
UPLANDER	2008 - 2005		24"	22"	16"
VENTURE	2005 - 1997		24"	24"	16"
CHRYSLER					
300	2009 - 2005		22"	22"	
300M	2004 - 1999		24"	22"	
ASPEN	2009 - 2007		26"	21"	
CIRRUS	2000 - 1995		22"	22"	
CONCORDE	2004 - 1997		24"	22"	
CONCORDE	1996 - 1995		24"	24"	
CONQUEST	1989 - 1987		19"	19"	17"
CORDOBA	1983 - 1980		18"	18"	
CROSSFIRE	2008 - 2005		20"	22"	
GRAND VOYAGER	2000 - 2000		28"	28"	18"
IMPERIAL	1993 - 1981		18"	18"	
LEBARON	1995 - 1994		19"	19"	
LEBARON	1993 - 1990		18"	18"	
LEBARON	1989 - 1986	GTS	16"	16"	16"
LEBARON	1989 - 1986	Wagon	16"	16"	13"
LEBARON	1985 - 1982		16"	16"	
LHS	2001 - 1999		24"	22"	
LHS	1998 - 1995		24"	24"	
LHS	1994 - 1993		24"	22"	
NEW YORKER	1996 - 1995		24"	24"	
NEW YORKER	1994 - 1994		24"	22"	
NEW YORKER	1993 - 1989		18"	18"	
PACIFICA	2008 - 2005		22"	22"	14"
PROWLER	2002 - 2002		17"	19"	
PT CRUISER	2009 - 2001		20"	21"	16"
SEBRING	2009 - 2007		24"	22"	
SEBRING	2006 - 1997	Convertible	22"	22"	
SEBRING	2005 - 1995	Coupe	24"	21"	
SEBRING	2005 - 2002	Sedan	22"	22"	
SEBRING	2001 - 1995	Sedan	24"	22"	
SEBRING	1996 - 1996	Convertible	20"	20"	
SEBRING	1995 - 1995	Convertible	24"	22"	
TC MASERATI	1991 - 1989		18"	18"	
TOWN & COUNTRY	2009 - 2008		26"	20"	
TOWN & COUNTRY	2007 - 2001		28"	28"	16"
TOWN & COUNTRY	2000 - 1996		28"	28"	18"

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
TOWN & COUNTRY	1995 - 1995		22"	22"	18"
TOWN & COUNTRY	1994 - 1994		22"	18"	18"
TOWN & COUNTRY	1993 - 1990		18"	18"	16"
VOYAGER	2003 - 2001		28"	28"	16"
VOYAGER	2000 - 2000		28"	28"	18"
DAEWOO					
LANOS	2002 - 1999		19"	19"	
LEGANZA	2002 - 1999		22"	19"	
NUBIRA	2002 - 1999		20"	20"	15"
DAIHATSU					
CHARADE	1992 - 1990		17"	17"	13"
ROCKY	1992 - 1990		17"	17"	13"
DODGE					
400	1983 - 1982		16"	16"	
600	1988 - 1983		16"	16"	
ARIES	1989 - 1981		16"	16"	13"
AVENGER	2009 - 2008		24"	22"	
AVENGER	2000 - 1995		24"	22"	
B150	1994 - 1985		16"	16"	
B250	1994 - 1985		16"	16"	
B350	1994 - 1981		16"	16"	
CALIBER	2009 - 2007		24"	17"	12"
CARAVAN	2007 - 2001		28"	28"	16"
CARAVAN	2000 - 1996		28"	28"	18"
CARAVAN	1995 - 1995		22"	22"	18"
CARAVAN	1994 - 1993		22"	18"	18"
CARAVAN	1992 - 1991		18"	18"	18"
CARAVAN	1990 - 1984		18"	18"	16"
CHALLENGER	2009 - 2009		22"	22"	
CHARGER	2009 - 2006		22"	22"	
CHARGER	1987 - 1983		16"	16"	18"
COLT	1994 - 1993		20"	19"	
COLT	1992 - 1991		20"	17"	
COLT	1990 - 1989		19"	17"	
COLT	1990 - 1989	Wagon	19"	18"	
COLT	1988 - 1980		17"	17"	16"
D50	1982 - 1982	Pick-up	16"	16"	
DAKOTA	2009 - 2005		21"	21"	
DAKOTA	2004 - 1997		20"	20"	
DAKOTA	1996 - 1987		18"	18"	
DAYTONA	1993 - 1984		18"	18"	
DAYTONA	1987 - 1987	Shelby Z	18"	18"	20"
DIPLOMAT	1989 - 1980		18"	18"	
DURANGO	2009 - 2004		26"	21"	
DURANGO	2003 - 1998		20"	20"	16"
DYNASTY	1993 - 1988		18"	18"	
GRAND CARAVAN	2009 - 2008		26"	20"	
GRAND CARAVAN	2007 - 2001		28"	28"	16"
GRAND CARAVAN	2000 - 1996		28"	28"	18"
GRAND CARAVAN	1995 - 1995		22"	22"	18"
GRAND CARAVAN	1994 - 1993		22"	18"	18"
GRAND CARAVAN	1992 - 1991		18"	18"	18"

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
GRAND CARAVAN	1990 - 1988		18"	18"	16"
INTREPID	2004 - 1997		24"	22"	
INTREPID	1996 - 1995		24"	24"	
INTREPID	1994 - 1993		24"	22"	
JOURNEY	2009 - 2009		24"	19"	
LANCER	1989 - 1985		18"	18"	
MAGNUM	2008 - 2005		22"	22"	
MINI RAM	1988 - 1984		18"	18"	16"
MIRADA	1983 - 1980		18"	18"	
MONACO	1992 - 1990		20"	20"	
NEON	2005 - 2000		22"	19"	
NEON	1999 - 1995		21"	18"	
NITRO	2009 - 2007		19"	19"	
OMNI	1990 - 1980		16"	16"	18"
RAM 1500	2009 - 2009		22"	22"	
RAM 1500	2008 - 2004		24"	24"	
RAM 1500	1998 - 1994		20"	20"	
RAM 1500 PICKUP	2003 - 2002		24"	24"	
RAM 1500 PICKUP	2001 - 1999		20"	20"	
RAM 1500 VAN	2003 - 1999		19"	19"	
RAM 2500	2009 - 2004		24"	24"	
RAM 2500	1998 - 1994		20"	20"	
RAM 2500 PICKUP	2003 - 2002		24"	24"	
RAM 2500 PICKUP	2001 - 1999		20"	20"	
RAM 2500 VAN	2003 - 2002		24"	24"	
RAM 2500 VAN	2001 - 1999		20"	20"	
RAM 3500	2009 - 2004		24"	24"	
RAM 3500	1998 - 1994		20"	20"	
RAM 3500 PICKUP	2003 - 2002		24"	24"	
RAM 3500 PICKUP	2001 - 1999		20"	20"	
RAM 3500 VAN	2003 - 1999		19"	19"	
RAM 50	1993 - 1990		17"	17"	
RAMCHARGER	1993 - 1980		18"	18"	
SHADOW	1994 - 1987		18"	18"	
SPIRIT	1995 - 1989		18"	18"	
SPRINTER	2007 - 2003		24"	22"	
ST. REGIS	1981 - 1980		18"	18"	
STEALTH	1996 - 1991		21"	20"	19"
STRATUS	2006 - 2002	Sedan	22"	22"	
STRATUS	2006 - 2002	Coupe	24"	21"	
STRATUS	2001 - 1995		22"	22"	
VIPER	2002 - 1992		16"	16"	
W100	1989 - 1986		18"	18"	
W150	1993 - 1980		18"	18"	
W200	1980 - 1980		18"	18"	
W250	1993 - 1981		18"	18"	
W300	1980 - 1980		18"	18"	
W350	1993 - 1981		18"	18"	
EAGLE					
MEDALLION	1989 - 1988		20"	20"	18"
PREMIER	1992 - 1988		20"	20"	
SUMMIT	1996 - 1993	Coupe	24"	21"	

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
SUMMIT	1996 - 1993	Wagon	19"	18"	16"
SUMMIT	1996 - 1993	Sedan	20"	19"	
SUMMIT	1992 - 1990	Sedan	20"	17"	
SUMMIT	1992 - 1991	Hatchback	20"	17"	
TALON	1998 - 1997		24"	22"	19"
TALON	1996 - 1995		24"	22"	18"
TALON	1994 - 1992		20"	20"	17"
TALON	1991 - 1990		19"	19"	
VISION	1998 - 1997		24"	22"	
VISION	1996 - 1995		24"	24"	
VISION	1994 - 1993		24"	22"	
FORD					
AEROSTAR	1997 - 1986		22"	22"	16"
ASPIRE	1997 - 1994		20"	16"	
BRONCO	1996 - 1980		18"	18"	
BRONCO II	1990 - 1987		18"	18"	13"
BRONCO II	1986 - 1984		18"	18"	
CONTOUR	2000 - 1995		22"	20"	
CROWN VICTORIA	2009 - 1992		22"	22"	
E-100 ECONOLINE	1983 - 1982		18"	18"	
E-100 ECONOLINE	1981 - 1980		20"	20"	
E-150	2009 - 2006		20"	20"	
E-250	2009 - 2006		20"	20"	
E-250 ECONOLINE	2005 - 1998		20"	20"	
E-250 ECONOLINE	1997 - 1992		22"	22"	
E-250 ECONOLINE	1991 - 1982		18"	18"	
E-250 ECONOLINE	1981 - 1980		20"	20"	
E-350 ECONOLINE	2005 - 1998		20"	20"	
E-350 ECONOLINE	1997 - 1992		22"	22"	
E-350 ECONOLINE	1991 - 1982		18"	18"	
E-350 ECONOLINE	1981 - 1980		20"	20"	
E-350 SUPER DUTY	2009 - 2006		20"	20"	
EDGE	2009 - 2007		26"	20"	
ESCAPE	2007 - 2001		20"	18"	
ESCORT	2003 - 2001	ZX2	20"	18"	
ESCORT	2000 - 1991		20"	18"	13"
ESCORT	1990 - 1981	Hatchback	18"	18"	18"
ESCORT	1990 - 1981	Wagon	18"	18"	14"
EXCURSION	2005 - 2000		20"	20"	16"
EXP	1988 - 1982		18"	18"	
EXPEDITION	2009 - 2007		20"	20"	17"
EXPEDITION	2006 - 2003		20"	20"	16"
EXPEDITION	2002 - 1997		22"	22"	16"
EXPLORER	2009 - 2006		20"	20"	13"
EXPLORER	2005 - 2002		22"	22"	16"
EXPLORER	2004 - 2001	Sport Trac	18"	18"	
EXPLORER	2001 - 1998		18"	18"	15"
EXPLORER	1997 - 1997	Early Model	18"	18"	13"
EXPLORER	1997 - 1997	Late Model	18"	18"	15"
EXPLORER	1996 - 1991		18"	18"	13"
F SUPER DUTY	1997 - 1997		22"	22"	
F SUPER DUTY	1996 - 1990		18"	18"	

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
F-100	1983 - 1980		18"	18"	
F-150	2009 - 2009		22"	22"	
F-150	2008 - 1999		20"	20"	
F-150	1998 - 1997		22"	22"	
F-150	1996 - 1980		18"	18"	
F-250	1999 - 1999		20"	20"	
F-250	1998 - 1997		22"	22"	
F-250	1996 - 1980		18"	18"	
F-250 SUPER DUTY	2009 - 1999		20"	20"	
F-350	1997 - 1997		22"	22"	
F-350	1996 - 1980		18"	18"	
F-350 SUPER DUTY	2009 - 1999		20"	20"	
F-450 SUPER DUTY	2009 - 1999		20"	20"	
F53	1997 - 1997		22"	22"	
F53	1996 - 1988		18"	18"	
F-550 SUPER DUTY	2007 - 1999		20"	20"	
F59	1994 - 1988		18"	18"	
FESTIVA	1993 - 1989		18"	18"	15"
FLEX	2009 - 2009		24"	22"	
FOCUS	2009 - 2008		22"	19"	
FOCUS	2007 - 2000		22"	19"	15"
FREESTAR	2007 - 2004		24"	20"	16"
FUSION	2009 - 2006		24"	19"	
GT	2006 - 2005		24"	24"	
LTD	1986 - 1980		18"	18"	
MUSTANG	2009 - 2005		22"	20"	
MUSTANG	2004 - 1994		20"	20"	
MUSTANG	1993 - 1983		16"	16"	
MUSTANG	1982 - 1980		16"	16"	18"
PROBE	1997 - 1993		20"	20"	20"
PROBE	1992 - 1989		19"	17"	20"
RANGER	2009 - 1983		18"	18"	
TAURUS	2006 - 1996		24"	20"	18"
TAURUS	2001 - 1996	Wagon	24"	20"	18"
TAURUS	1995 - 1986		20"	20"	15"
TAURUS	1995 - 1986	Wagon	20"	20"	15"
TEMPO	1994 - 1986		20"	20"	
TEMPO	1985 - 1984		19"	19"	
THUNDERBIRD	2005 - 2002		24"	22"	
THUNDERBIRD	1997 - 1990		22"	22"	
THUNDERBIRD	1989 - 1989		24"	20"	
THUNDERBIRD	1988 - 1983		18"	18"	
THUNDERBIRD	1982 - 1980		16"	16"	
WINDSTAR	2003 - 1995		24"	20"	16"
GEO					
METRO	1997 - 1995		20"	19"	
METRO	1994 - 1993		20"	18"	
METRO	1992 - 1989		18"	18"	15"
PRIZM	1997 - 1993		20"	18"	
PRIZM	1992 - 1989		19"	17"	
SPECTRUM	1989 - 1989		18"	18"	
STORM	1993 - 1990		22"	22"	20"

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
TRACKER	1997 - 1989		17"	17"	15"
GMC					
C1500	1998 - 1988		18"	18"	
C1500	1986 - 1980		16"	16"	
C1500 SUBURBAN	1999 - 1995		18"	18"	13"
C1500 SUBURBAN	1994 - 1992		18"	18"	
C1500 SUBURBAN	1986 - 1980		16"	16"	
C2500	2000 - 1984		18"	18"	
C2500	1983 - 1980		16"	16"	
C2500 SUBURBAN	1999 - 1995		18"	18"	13"
C2500 SUBURBAN	1994 - 1992		18"	18"	
C2500 SUBURBAN	1986 - 1980		16"	16"	
C3500	2002 - 2001		22"	22"	
C3500	2000 - 1988		18"	18"	
C3500	1986 - 1980		16"	16"	
CABALLERO	1987 - 1980		18"	18"	
CANYON	2009 - 2004		22"	19"	
ENVOY	2009 - 2007		22"	22"	
ENVOY	2006 - 2002		22"	22"	16"
G1500	1995 - 1993		18"	18"	
G1500	1992 - 1980		16"	16"	
G2500	1995 - 1993		18"	18"	
G2500	1992 - 1980		16"	16"	
G3500	1996 - 1996		22"	22"	
G3500	1995 - 1993		18"	18"	
G3500	1992 - 1980		16"	16"	
JIMMY	2001 - 1995	S-15	20"	20"	14"
JIMMY	1991 - 1987		18"	18"	14"
JIMMY	1991 - 1991	S-15	18"	18"	14"
JIMMY	1990 - 1983	S-15	16"	16"	
JIMMY	1986 - 1980		16"	16"	
K1500	1999 - 1988		18"	18"	
K1500	1986 - 1980		16"	16"	
K1500 SUBURBAN	1999 - 1995		18"	18"	13"
K1500 SUBURBAN	1994 - 1992		18"	18"	
K1500 SUBURBAN	1986 - 1980		16"	16"	
K2500	2000 - 1988		18"	18"	
K2500	1986 - 1980		16"	16"	
K2500 SUBURBAN	1999 - 1995		18"	18"	13"
K2500 SUBURBAN	1994 - 1992		18"	18"	
K2500 SUBURBAN	1986 - 1980		16"	16"	
K3500	2000 - 1988		18"	18"	
K3500	1986 - 1980		16"	16"	
P3500	1994 - 1990		18"	18"	
R1500 SUBURBAN	1991 - 1987		16"	16"	
R2500 SUBURBAN	1991 - 1987		16"	16"	
S15	1990 - 1982	Pick-up	16"	16"	
SAFARI	2005 - 1993		18"	18"	13"
SAFARI	1992 - 1985		18"	18"	
SAVANA 1500	2009 - 1996		22"	22"	
SAVANA 2500	2009 - 1996		22"	22"	
SAVANA 3500	2009 - 1996		22"	22"	

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
SIERRA 1500	2007 - 2007	Classic	22"	22"	
SIERRA 1500	2006 - 1999		22"	22"	
SIERRA 1500 HD	2007 - 2007	Classic	22"	22"	
SIERRA 1500 HD	2006 - 2001		22"	22"	
SIERRA 2500	2004 - 2001		22"	22"	
SIERRA 2500	2000 - 1999		18"	18"	
SIERRA 2500 HD	2007 - 2007	Classic	22"	22"	
SIERRA 2500 HD	2006 - 2001		22"	22"	
SIERRA 3500	2007 - 2007	Classic	22"	22"	
SIERRA 3500	2006 - 2001		22"	22"	
SIERRA C3	2001 - 2001		22"	22"	
SIERRA DENALI	2007 - 2007	Classic	22"	22"	
SIERRA DENALI	2006 - 2002		22"	22"	
SONOMA	2004 - 1994		20"	20"	
SONOMA	1993 - 1991		16"	16"	
SYCLONE	1991 - 1991		16"	16"	
TYPHOON	1993 - 1992		16"	16"	13"
V1500	1987 - 1987		16"	16"	
V1500 SUBURBAN	1991 - 1987		16"	16"	
V2500	1987 - 1987		16"	16"	
V2500 SUBURBAN	1991 - 1987		16"	16"	
V3500	1991 - 1987		16"	16"	
YUKON	2009 - 2009		22"	22"	
YUKON	2006 - 2000		22"	22"	16"
YUKON	1999 - 1993		18"	18"	13"
YUKON	1992 - 1992		16"	16"	13"
YUKON DENALI	2006 - 2005		22"	22"	16"
YUKON DENALI XL	2006 - 2005		22"	22"	16"
YUKON XL	2009 - 2009		22"	22"	
YUKON XL	2006 - 2000		22"	22"	16"
HONDA					
ACCORD	2009 - 2008		26"	19"	
ACCORD	2007 - 2003		26"	18"	
ACCORD	2002 - 1998		24"	19"	
ACCORD	1997 - 1990		24"	19"	15"
ACCORD	1989 - 1986		19"	19"	19"
ACCORD	1985 - 1980		17"	17"	16"
CIVIC	2009 - 2006	Sedan	26"	22"	
CIVIC	2005 - 2004	Hatchback	24"	16"	
CIVIC	2005 - 2003	Si	24"	19"	
CIVIC	2005 - 2003	Sedan	21"	19"	
CIVIC	2005 - 2001	Exc. Si	21"	19"	
CIVIC	2002 - 2001	Si	21"	19"	
CIVIC	2000 - 1999		20"	18"	
CIVIC	1998 - 1996		20"	18"	15"
CIVIC	1995 - 1992		22"	18"	
CIVIC	1992 - 1992	Wagon	22"	18"	
CIVIC	1991 - 1988	Wagon	20"	19"	16"
CIVIC	1991 - 1988		20"	19"	16"
CIVIC	1987 - 1986	Wagon	18"	18"	16"
CIVIC	1987 - 1986		18"	18"	16"
CIVIC	1985 - 1984	Wagon	18"	18"	15"

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
CIVIC	1985 - 1984		18"	18"	15"
CIVIC	1983 - 1980	Wagon	17"	17"	13"
CIVIC	1983 - 1980		17"	17"	13"
CIVIC DEL SOL	1997 - 1993		22"	19"	
CR-V	2009 - 2007		26"	16"	
CR-V	2006 - 2002		21"	20"	12"
CR-V	2001 - 1997		20"	19"	12"
CRX	1991 - 1990		20"	20"	17"
CRX	1989 - 1988		19"	19"	17"
ELEMENT	2009 - 2003		20"	20"	
EV PLUS	1999 - 1999		22"	19"	
EV PLUS	1998 - 1998		24"	22"	
FIT	2009 - 2007		24"	16"	
INSIGHT	2006 - 2000		22"	19"	16"
ODYSSEY	2009 - 2005		26"	22"	
ODYSSEY	2004 - 1999		24"	21"	15"
ODYSSEY	1998 - 1995		24"	24"	15"
PASSPORT	2002 - 1998		19"	19"	15"
PASSPORT	1997 - 1994		18"	18"	
PILOT	2009 - 2009		22"	21"	
PILOT	2008 - 2003		24"	21"	14"
PRELUDE	2001 - 1997		21"	19"	
PRELUDE	1996 - 1992		22"	19"	
PRELUDE	1991 - 1988		20"	19"	
PRELUDE	1987 - 1983		19"	19"	
PRELUDE	1983 - 1983	Late Model	19"	19"	
RIDGELINE	2009 - 2006		24"	22"	
S2000	2009 - 2000		16"	20"	
HUMMER					
H1	2006 - 2002		12"	12"	
H2	2009 - 2004		17"	17"	12"
H3	2009 - 2006		17"	17"	12"
H3T	2009 - 2009		17"	17"	
HYUNDAI					
ACCENT	2009 - 2006		22"	16"	
ACCENT	2005 - 2004		20"	18"	18"
ACCENT	2003 - 2001		20"	18"	
ACCENT	2000 - 2000		20"	18"	18"
ACCENT	1999 - 1996		20"	18"	20"
AZERA	2009 - 2006		24"	20"	
ELANTRA	2009 - 2007		24"	18"	
ELANTRA	2006 - 2001	Wagon	20"	18"	20"
ELANTRA	2006 - 2001		20"	18"	20"
ELANTRA	2000 - 1996		20"	18"	14"
ELANTRA	2000 - 1996	Wagon	20"	18"	14"
ELANTRA	1995 - 1992		20"	19"	
ELANTRA	1995 - 1992	Wagon	20"	19"	
ENTOURAGE	2009 - 2007		26"	18"	
EXCEL	1994 - 1990		18"	18"	16"
EXCEL	1989 - 1988		17"	17"	17"
EXCEL	1987 - 1986		16"	16"	16"
PONY	1987 - 1984		17"	17"	17"

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
SANTA FE	2009 - 2007		24"	18"	
SANTA FE	2006 - 2005		24"	20"	13"
SANTA FE	2004 - 2001		22"	20"	13"
SCOUPE	1995 - 1991		19"	18"	
SONATA	2009 - 2006		24"	19"	
SONATA	2005 - 1999		22"	20"	
SONATA	1998 - 1995		20"	20"	
SONATA	1994 - 1989		20"	18"	
STELLAR	1988 - 1985		18"	18"	
TIBURON	2008 - 2005		22"	18"	
TIBURON	2004 - 1997		22"	18"	20"
TUCSON	2009 - 2005		24"	16"	
XG300	2001 - 2001		20"	20"	
XG350	2005 - 2002		20"	20"	
INFINITI					
EX35	2009 - 2008		22"	18"	
FX35	2008 - 2003		22"	20"	
FX45	2008 - 2003		22"	20"	
G20	2002 - 1991		21"	19"	
G35	2008 - 2007	Sedan	26"	16"	
G35	2007 - 2003	Coupe	24"	17"	
G35	2006 - 2003	Sedan	22"	18"	
G37	2009 - 2008	Coupe	26"	16"	
G37	2009 - 2009	Sedan	26"	16"	
G37	2008 - 2008	Sedan	24"	17"	
I30	2001 - 2000		26"	17"	
I30	1999 - 1996		22"	21"	
I35	2004 - 2002		26"	17"	
M30	1992 - 1990		21"	19"	
M35	2009 - 2006		24"	19"	
M45	2008 - 2006		24"	19"	
M45	2004 - 2003		21"	19"	
Q45	2006 - 2002		26"	18"	
Q45	2001 - 1997		22"	20"	
Q45	1996 - 1990		21"	21"	
QX4	2003 - 1997		22"	21"	12"
QX56	2009 - 2004		24"	22"	
ISUZU					
AMIGO	2000 - 1998		19"	19"	
AMIGO	1994 - 1989		18"	18"	
ASCENDER	2008 - 2003		22"	22"	16"
AXIOM	2004 - 2002		20"	19"	
HOMBRE	2000 - 1996		20"	20"	
I-280	2006 - 2006		22"	19"	
I-290	2008 - 2007		22"	19"	
I-350	2006 - 2006		22"	19"	
I-370	2008 - 2007		22"	19"	
I-MARK	1989 - 1989		18"	18"	
I-MARK	1988 - 1985		18"	18"	15"
I-MARK	1984 - 1981		16"	16"	
IMPULSE	1992 - 1991		22"	22"	20"
IMPULSE	1990 - 1990		22"	22"	

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
OASIS	1999 - 1996		24"	24"	15"
PICKUP	1995 - 1981		18"	18"	
RODEO	2004 - 2002		19"	19"	
RODEO	2001 - 1998		19"	19"	14"
RODEO	1997 - 1991		18"	18"	13"
RODEO SPORT	2003 - 2002	Sport	19"	19"	
RODEO SPORT	2001 - 2001	Sport	19"	19"	14"
STYLUS	1993 - 1991		22"	20"	
TROOPER	2002 - 1992		20"	20"	15"
TROOPER	1991 - 1984		17"	17"	16"
VEHICROSS	2001 - 1999		24"	17"	
JAGUAR					
S-TYPE	2008 - 2000		22"	22"	
SUPER V8	2009 - 2005		24"	19"	
VANDEN PLAS	2008 - 2006		24"	19"	
VANDEN PLAS	2005 - 2004		22"	19"	
VANDEN PLAS	2003 - 1994		21"	21"	
XF	2009 - 2009		22"	18"	
XJ12	1996 - 1994		21"	21"	
XJ6	1997 - 1993		21"	21"	
XJ6	1992 - 1990		21"		
XJ8	2009 - 1998		21"	21"	
XJR	2008 - 2006		24"	19"	
XJR	2005 - 2004		22"	19"	
XJR	2003 - 1995		21"	21"	
XJRS	1993 - 1993		21"	21"	
XJS	1996 - 1990		15"	15"	
XK	2009 - 2007		21"	21"	
XK8	2006 - 1997		21"	21"	
XKR	2009 - 2000		21"	21"	
X-TYPE	2007 - 2002		22"	19"	
JEEP					
CHEROKEE	2001 - 1984		18"	18"	12"
CHEROKEE	1983 - 1980		24"	22"	
COMANCHE	1992 - 1986		18"	18"	
COMMANDER	2009 - 2006		18"	18"	
COMPASS	2009 - 2007		22"	20"	
GRAND CHEROKEE	2009 - 2005		21"	21"	
GRAND CHEROKEE	2004 - 1993		20"	20"	13"
GRAND WAGONEER	1993 - 1993		20"	20"	13"
GRAND WAGONEER	1991 - 1984		16"	16"	12"
J10	1988 - 1980		16"	16"	
J20	1988 - 1980		16"	16"	
LIBERTY	2009 - 2002		19"	19"	
PATRIOT	2009 - 2007		22"	20"	
SCRAMBLER	1985 - 1981		12"	12"	
TJ	2001 - 1997		13"	13"	18"
WAGONEER	1990 - 1984		18"	18"	
WAGONEER	1983 - 1980		16"	16"	
WRANGLER	2009 - 2007		15"	15"	
WRANGLER	2006 - 1997		13"	13"	18"
WRANGLER	1995 - 1988		12"	12"	16"

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
WRANGLER	1987 - 1987		12"	12"	
KIA					
AMANTI	2009 - 2009		24"	18"	
AMANTI	2008 - 2004		24"	18"	
BORREGO	2009 - 2009		24"	20"	
OPTIMA	2009 - 2007		24"	18"	
OPTIMA	2006 - 2001		22"	20"	
RIO	2009 - 2006		22"	16"	
RIO	2005 - 2001		21"	18"	14"
RIO5	2008 - 2006		22"	16"	14"
RONDO	2009 - 2007		26"	16"	
SEDONA	2009 - 2006		26"	18"	
SEDONA	2005 - 2002		24"	24"	16"
SEPHIA	2001 - 1994		21"	19"	
SORENTO	2009 - 2003		24"	18"	14"
SPECTRA	2009 - 2004		24"	16"	
SPECTRA	2003 - 2000		21"	19"	19"
SPORTAGE	2009 - 2005		24"	16"	
SPORTAGE	2002 - 1995		20"	20"	16"
LAND ROVER					
DEFENDER 110	1993 - 1993		12"	12"	12"
DEFENDER 90	1997 - 1994		12"	12"	12"
DISCOVERY	2004 - 1994		18"	18"	14"
FREELANDER	2005 - 2002		22"	21"	
LR3	2009 - 2009		22"	22"	
LR3	2008 - 2005		22"	22"	16"
RANGE ROVER	2008 - 2006	Sport	22"	22"	
RANGE ROVER	2001 - 1995		22"	22"	19"
RANGE ROVER	1994 - 1990		18"	18"	
LEXUS					
ES250	1991 - 1990		20"	20"	
ES300	2003 - 2002		24"	20"	
ES300	2001 - 1997		22"	18"	
ES300	1996 - 1992		21"	19"	
ES330	2006 - 2004		24"	20"	
ES350	2009 - 2007		24"	18"	
GS300	2006 - 2006		24"	19"	
GS300	2005 - 1998		24"	20"	
GS300	1997 - 1993		21"	19"	
GS350	2009 - 2009		24"	19"	
GS400	2000 - 1998		24"	20"	
GS430	2007 - 2006		24"	19"	
GS430	2005 - 2001		24"	20"	
GS450H	2009 - 2007		24"	19"	
GS460	2009 - 2008		24"	19"	
GX470	2009 - 2003		22"	21"	
IS F	2009 - 2009		22"	20"	
IS250	2009 - 2006		22"	20"	
IS300	2005 - 2001		22"	20"	
IS350	2009 - 2006		22"	20"	
LS400	2000 - 1990		22"	16"	
LS430	2006 - 2001		24"	16"	

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
LS460	2009 - 2009		24"	17"	
LS460	2008 - 2007		24"	17"	
LS600H	2009 - 2009		24"	17"	
LS600H	2008 - 2008		24"	17"	
LX450	1997 - 1996		18"	16"	
LX470	2007 - 2000		24"	22"	16"
LX470	1999 - 1998		20"	16"	16"
LX570	2009 - 2009		24"	22"	
LX570	2008 - 2008		24"	22"	
RX300	2003 - 1999		24"	21"	16"
RX330	2006 - 2004		26"	22"	
RX350	2009 - 2007		26"	22"	
RX400H	2008 - 2006		26"	22"	
SC300	2000 - 1992		21"	20"	
SC400	2000 - 1992		21"	20"	
SC430	2009 - 2002		24"	20"	
LINCOLN					
AVIATOR	2004 - 2003		22"	22"	
BLACKWOOD	2002 - 2002		20"	20"	
CONTINENTAL	2002 - 1998		24"	20"	
CONTINENTAL	1997 - 1988		20"	20"	
CONTINENTAL	1987 - 1980		18"	18"	
LS	2006 - 2000		24"	19"	
MARK LT	2008 - 2006		20"	20"	
MARK VI	1983 - 1980		18"	18"	
MARK VII	1992 - 1984		18"	18"	
MARK VIII	1998 - 1993		22"	22"	
MKX	2009 - 2007		26"	20"	
MKZ	2009 - 2007		24"	19"	
NAVIGATOR	2009 - 2007		20"	20"	17"
NAVIGATOR	2006 - 2005		20"	20"	
TOWN CAR	2009 - 2009		22"	20"	
TOWN CAR	2008 - 1990		22"	22"	
TOWN CAR	1989 - 1981		18"	18"	
VERSAILLES	1980 - 1980		16"	16"	
ZEPHYR	2006 - 2006		24"	19"	
MAZDA					
3	2009 - 2004		22"	18"	
323	1995 - 1990		21"	18"	
323	1989 - 1986		18"	18"	
5	2009 - 2006		26"	16"	
6	2009 - 2009	G	24"	18"	
6	2008 - 2003		22"	18"	
626	2002 - 1998		20"	19"	
626	1997 - 1993		21"	20"	
626	1992 - 1988		19"	19"	22"
626	1987 - 1986		18"	18"	
929	1995 - 1992		21"	20"	
929	1991 - 1988		20"	19"	
B2200	1993 - 1988		18"	18"	
B2300	2009 - 1994		18"	18"	
B2500	2001 - 1998		18"	18"	

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
B2600	1993 - 1988		18"	18"	
B3000	2007 - 1994		18"	18"	
B4000	2009 - 1994		18"	18"	
CX-7	2009 - 2008		26"	16"	
CX-7	2007 - 2007		24"	16"	
CX-9	2009 - 2007		26"	16"	
GLC	1983 - 1980		15"	15"	13"
MIATA	2005 - 1990		18"	18"	
MILLENIA	2002 - 1998		20"	19"	
MILLENIA	1997 - 1995		21"	20"	
MPV	2006 - 2000		24"	24"	16"
MPV	1998 - 1989		22"	20"	17"
MX-3	1996 - 1992		21"	18"	21"
MX-5 MIATA	2009 - 2006		18"	18"	
MX-6	1997 - 1993		20"	20"	
MX-6	1992 - 1988		19"	19"	
NAVAJO	1994 - 1991		18"	18"	13"
PROTEGE	2003 - 1990		21"	19"	
PROTEGES	2003 - 2002		21"	19"	
RX-7	1995 - 1993		20"	20"	18"
RX-7	1991 - 1986		20"	20"	22"
RX-8	2009 - 2004		20"	18"	
TRIBUTE	2006 - 2004		20"	18"	
TRIBUTE	2003 - 2001		19"	19"	
MERCEDES-BENZ					
190D	1989 - 1986	Single Blade	24"		
260E	1989 - 1987	Single Blade	24"		
300CD	1981 - 1980		20"	20"	
300CE	1993 - 1988	Single Blade	24"		
300D	1993 - 1987	Single Blade	24"		
300D	1981 - 1980		20"	20"	
300E	1993 - 1986	Single Blade	24"		18"
300SD	1993 - 1992	Single Blade	24"		
300SD	1985 - 1981		21"	21"	
300SDL	1987 - 1986		21"	21"	
300SE	1993 - 1992	Single Blade	24"		
300SE	1991 - 1988		21"	21"	
300SEL	1991 - 1988		21"	21"	
300SL	1993 - 1990	Single Blade	24"		
300TD	1981 - 1980		20"	20"	
300TE	1993 - 1988		22"	22"	
350SD	1991 - 1991		21"	21"	
350SDL	1991 - 1990		21"	21"	
400E	1993 - 1992	Single Blade	24"		
400SE	1992 - 1992	Single Blade	24"		
400SEL	1993 - 1993	Single Blade	24"		
420SEL	1991 - 1986		21"	21"	
500E	1993 - 1992	Single Blade	24"		
500SEC	1993 - 1993	Single Blade	24"		
500SEL	1993 - 1992	Single Blade	24"		
500SL	1993 - 1990	Single Blade	24"		
560SEC	1991 - 1986		21"	21"	

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
560SEL	1991 - 1986		21"	21"	
560SL	1989 - 1986		18"	18"	
600SEC	1993 - 1993	Single Blade	24"		
600SEL	1993 - 1992	Single Blade	24"		
600SL	1993 - 1993	Single Blade	24"		
C220	1996 - 1994	Single Blade	24"		16"
C230	2003 - 2002		24"	22"	16"
C230	2000 - 1997	Single Blade	24"		16"
C240	2003 - 2001		24"	22"	16"
C280	2000 - 1994	Single Blade	24"		16"
C32 AMG	2003 - 2002		24"	22"	16"
C320	2003 - 2001		24"	22"	16"
C36 AMG	1997 - 1995	Single Blade	24"		16"
C43 AMG	2000 - 1998	Single Blade	24"		16"
CLK320	2003 - 1998	Single Blade	24"		
CLK430	2003 - 1999	Single Blade	24"		
CLK500	2003 - 2003	Single Blade	24"		
CLK55 AMG	2003 - 2001	Single Blade	24"		
E300D	1999 - 1998	Single Blade	24"		16"
E300D	1997 - 1995	Single Blade	24"		18"
E320	2002 - 2002		24"	24"	16"
E320	2001 - 1998	Single Blade	24"		16"
E320	1997 - 1994	Single Blade	24"		18"
E420	1997 - 1994	Single Blade	24"		18"
E430	2002 - 2002		24"	24"	16"
E430	2001 - 1998	Single Blade	24"		16"
E500	1994 - 1994	Single Blade	24"		18"
E55 AMG	2002 - 2002		24"	24"	16"
E55 AMG	2001 - 1999	Single Blade	24"		16"
G500	2007 - 2002		16"	16"	15"
G55 AMG	2009 - 2003		16"	16"	15"
G550	2009 - 2008		16"	16"	15"
ML320	2003 - 1998		22"	22"	17"
ML350	2005 - 2003		22"	22"	17"
ML430	2001 - 1999		22"	22"	17"
ML500	2005 - 2002		22"	22"	17"
ML55 AMG	2003 - 2000		22"	22"	17"
SL320	1997 - 1994		24"	24"	
SL500	2006 - 2003		26"	26"	
SL500	2001 - 1994		24"	24"	
SL55 AMG	2008 - 2003		26"	26"	
SL550	2008 - 2007		26"	26"	
SL600	2008 - 2004		26"	26"	
SL600	2001 - 1994		24"	24"	
SL65 AMG	2008 - 2005		26"	26"	
SLK230	2004 - 1998		22"	22"	
SLK32 AMG	2004 - 2002		22"	22"	
SLK320	2004 - 2001		22"	22"	
MERCURY					
BOBCAT	1980 - 1980		16"	16"	
CAPRI	1994 - 1991		20"	18"	
CAPRI	1986 - 1983		16"	16"	

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
CAPRI	1982 - 1980		16"	16"	18"
COLONY PARK	1991 - 1987		18"	18"	
COUGAR	2002 - 1999		22"	20"	22"
COUGAR	1997 - 1990		22"	22"	
COUGAR	1989 - 1989		24"	20"	
COUGAR	1988 - 1983		18"	18"	
COUGAR	1982 - 1980		16"	16"	
GRAND MARQUIS	2009 - 1992		22"	22"	
GRAND MARQUIS	1991 - 1991	Late Model	22"	22"	
GRAND MARQUIS	1991 - 1991	Early Model	18"	18"	
GRAND MARQUIS	1990 - 1980		18"	18"	
LN7	1983 - 1982		18"	18"	15"
LYNX	1987 - 1981		18"	18"	15"
MARAUDER	2004 - 2003		22"	22"	
MARINER	2007 - 2007		20"	18"	
MARINER	2006 - 2005		19"	18"	
MARQUIS	1986 - 1986		18"	18"	
MARQUIS	1985 - 1984	Wagon	18"	18"	16"
MARQUIS	1983 - 1980		18"	18"	
MILAN	2009 - 2006		24"	19"	
MONARCH	1980 - 1980		16"	16"	
MONTEREY	2006 - 2004		24"	20"	26"
MOUNTAINEER	2009 - 2006		20"	20"	13"
MOUNTAINEER	2001 - 1999		18"	18"	15"
MOUNTAINEER	1998 - 1997		18"	18"	12"
MYSTIQUE	2000 - 1995		22"	20"	
SABLE	2005 - 1996		24"	20"	18"
SABLE	1995 - 1986		20"	20"	15"
TOPAZ	1994 - 1986		20"	20"	
TOPAZ	1985 - 1984		18"	18"	
TRACER	1999 - 1994		20"	18"	14"
TRACER	1989 - 1987		18"	18"	
VILLAGER	2002 - 2000		22"	22"	14"
VILLAGER	1999 - 1993		22"	22"	12"
ZEPHYR	1983 - 1980		16"	16"	16"
MINI					
COOPER	2009 - 2002		18"	19"	
MITSUBISHI					
3000GT	1999 - 1991		21"	20"	19"
DIAMANTE	2004 - 1997		22"	20"	
DIAMANTE	1996 - 1992		20"	19"	16"
ECLIPSE	2009 - 2006		24"	22"	17"
ECLIPSE	2005 - 2001		24"	21"	22"
ECLIPSE	2000 - 2000		24"	21"	18"
ECLIPSE	1999 - 1997		24"	22"	18"
ECLIPSE	1996 - 1995		24"	22"	
ECLIPSE	1994 - 1992		20"	20"	19"
ECLIPSE	1991 - 1990		19"	19"	17"
ENDEAVOR	2008 - 2004		26"	21"	
EXPO	1995 - 1992		22"	18"	16"
GALANT	2009 - 2004		26"	19"	
GALANT	2003 - 1999		24"	18"	

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
GALANT	1998 - 1994		21"	19"	
GALANT	1993 - 1990		19"	18"	
GALANT	1989 - 1989		19"	17"	
GALANT	1987 - 1985		17"	17"	
LANCER	2009 - 2008		26"	18"	
LANCER	2007 - 2002		24"	18"	17"
MIGHTY MAX	1996 - 1990	Pick-up	17"	17"	
MIRAGE	2002 - 1997		21"	19"	
MIRAGE	1996 - 1991		20"	19"	
MIRAGE	1990 - 1989		19"	17"	13"
MIRAGE	1988 - 1985		17"	16"	16"
MONTERO	2006 - 2000		20"	20"	16"
MONTERO	1999 - 1992		19"	19"	15"
MONTERO	1991 - 1985		16"	16"	13"
MONTERO	1984 - 1983		16"	16"	
MONTERO SPORT	2004 - 1997		20"	20"	17"
OUTLANDER	2009 - 2007		24"	21"	
OUTLANDER	2006 - 2003		22"	19"	
PRECIS	1994 - 1988		18"	18"	16"
RAIDER	2009 - 2006		21"	21"	
SIGMA	1990 - 1989		17"	17"	
TREDIA	1987 - 1983		17"	17"	
VAN	1990 - 1987		17"	17"	15"
NISSAN					
200SX	1998 - 1995		21"	19"	
200SX	1988 - 1984		19"	19"	17"
240SX	1998 - 1995		21"	20"	
240SX	1994 - 1989		20"	20"	
300ZX	1996 - 1995		21"	21"	16"
300ZX	1994 - 1990		21"	21"	19"
300ZX	1989 - 1986		19"	19"	19"
300ZX	1985 - 1984		17"	17"	19"
310	1982 - 1980		17"	17"	
350Z	2009 - 2003		20"	18"	18"
370Z	2009 - 2009		21"	19"	
720	1985 - 1980	Pick-up	16"	16"	
810	1981 - 1981		18"	18"	15"
ALTIMA	2009 - 2009		28"	17"	
ALTIMA	2008 - 2007		28"	17"	
ALTIMA	2006 - 2002		26"	17"	
ALTIMA	2001 - 1993		21"	20"	
ARMADA	2009 - 2005		24"	22"	
AXXESS	1991 - 1990		22"	22"	
FRONTIER	2009 - 2005		24"	18"	
FRONTIER	2004 - 1998		19"	19"	
MAXIMA	2009 - 2009		28"	17"	
MAXIMA	2008 - 2000		26"	17"	
MAXIMA	1999 - 1995		22"	21"	
MAXIMA	1994 - 1989		21"	20"	
MAXIMA	1988 - 1985		19"	19"	
MAXIMA	1984 - 1981		18"	18"	15"
MICRA	1991 - 1984		24"	24"	

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
MULTI	1988 - 1986		16"	16"	16"
MURANO	2009 - 2006		26"	16"	
MURANO	2005 - 2003		26"	19"	
NX	1993 - 1992		20"	19"	20"
NX	1991 - 1991		20"	19"	
PATHFINDER	2009 - 2005		24"	18"	
PATHFINDER	2004 - 1996		22"	21"	12"
PATHFINDER	1995 - 1991		19"	19"	12"
PATHFINDER	1990 - 1987		19"	19"	
PICKUP	1997 - 1995		19"	19"	
PULSAR NX	1990 - 1987		21"	21"	
QUEST	2009 - 2004		26"	18"	
QUEST	2002 - 1993		22"	22"	14"
ROGUE	2009 - 2008		26"	14"	
SENTRA	2009 - 2007		26"	16"	
SENTRA	2006 - 2000		22"	17"	
SENTRA	1999 - 1991		21"	19"	
SENTRA	1990 - 1987	Sedan	19"	18"	
SENTRA	1989 - 1987	Coupe	19"	18"	17"
SENTRA	1989 - 1987	Wagon	19"	18"	16"
SENTRA	1986 - 1982	Sedan	18"	18"	
SENTRA	1986 - 1983	Wagon	18"	18"	16"
SENTRA	1986 - 1986	Coupe	18"	18"	17"
STANZA	1992 - 1990		20"	20"	
STANZA	1989 - 1988		19"	19"	
STANZA	1987 - 1987		19"	19"	16"
STANZA	1986 - 1982		18"	18"	18"
TITAN	2009 - 2004		26"	22"	
VAN	1988 - 1987		22"	19"	
VERSA	2009 - 2007		26"	14"	
XTERRA	2009 - 2005		24"	18"	
XTERRA	2004 - 2000		19"	19"	
OLDSMOBILE					
88	1999 - 1992		22"	22"	
98	1996 - 1991		22"	22"	
98	1990 - 1988		19"	19"	
98	1987 - 1985	FWD	19"	19"	
98	1986 - 1980	RWD	18"	18"	
ACHIEVA	1998 - 1992		19"	19"	
ALERO	2004 - 1999		22"	17"	
AURORA	2003 - 1995		22"	22"	
BRAVADA	2004 - 2002		22"	22"	14"
BRAVADA	2001 - 1996		20"	20"	14"
BRAVADA	1994 - 1991		16"	16"	13"
CUSTOM CRUISER	1992 - 1991		22"	22"	16"
CUSTOM CRUISER	1990 - 1980		18"	18"	16"
CUTLASS	1999 - 1997		22"	19"	
CUTLASS	1987 - 1980		18"	18"	
CUTLASS CALAIS	1991 - 1985		19"	19"	
CUTLASS CIERA	1996 - 1984		18"	18"	
CUTLASS CRUISER	1990 - 1987		18"	18"	
CUTLASS SALON	1987 - 1980		18"	18"	

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
CUTLASS SUPREME	1997 - 1988		20"	20"	
CUTLASS SUPREME	1988 - 1988	RWD	18"	18"	
CUTLASS SUPREME	1987 - 1980		18"	18"	
DELTA 88	1991 - 1986		19"	19"	
DELTA 88	1985 - 1980		18"	18"	
FIRENZA	1988 - 1982		15"	15"	15"
INTRIGUE	2002 - 1998		22"	22"	
LSS	1999 - 1996		22"	22"	
REGENCY	1998 - 1997		22"	22"	
SILHOUETTE	2004 - 1997		24"	24"	16"
SILHOUETTE	1996 - 1990		24"	22"	13"
TORONADO	1992 - 1992		22"	22"	
TORONADO	1991 - 1986		19"	19"	
TORONADO	1985 - 1980		18"	18"	
PANOZ					
AIV ROADSTER	2000 - 1999		15"	15"	
PEUGEOT					
405	1991 - 1989		21"	21"	13"
504	1983 - 1980		16"	16"	
505	1991 - 1981		18"	18"	18"
604	1984 - 1980		18"	18"	
PLYMOUTH					
ACCLAIM	1995 - 1989		18"	18"	
BREEZE	2000 - 1996		22"	22"	
CARAVELLE	1989 - 1981		16"	16"	
COLT	1995 - 1993		20"	19"	
COLT	1994 - 1993	Vista	22"	18"	16"
COLT	1992 - 1991		20"	17"	
COLT	1992 - 1991	Vista	20"	18"	
COLT	1988 - 1987		17"	17"	16"
COLT	1988 - 1984	Vista	19"	19"	13"
CONQUEST	1986 - 1984		18"	18"	16"
EXPO	1989 - 1987		16"	16"	
GRAN FURY	1989 - 1980		18"	18"	
GRAND VOYAGER	2000 - 1996		28"	28"	18"
GRAND VOYAGER	1995 - 1995		22"	22"	
GRAND VOYAGER	1994 - 1994		22"	18"	18"
GRAND VOYAGER	1993 - 1991		18"	18"	18"
GRAND VOYAGER	1990 - 1988		18"	18"	16"
HORIZON	1990 - 1980		16"	16"	18"
LASER	1994 - 1994		20"	20"	
LASER	1993 - 1992		20"	20"	17"
NEON	2001 - 2000		22"	19"	
NEON	1999 - 1995		21"	18"	
PROWLER	2001 - 1997		17"	19"	
RELIANT	1989 - 1981	Wagon	16"	16"	13"
SCAMP	1983 - 1983		16"	16"	
SUNDANCE	1994 - 1987		18"	18"	
TURISMO	1985 - 1983		16"	16"	
VOYAGER	2000 - 1996		28"	28"	18"
VOYAGER	1995 - 1995		22"	22"	
VOYAGER	1994 - 1994		22"	18"	18"

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
VOYAGER	1993 - 1991		18"	18"	18"
VOYAGER	1990 - 1984		18"	18"	16"
PONTIAC					
6000	1991 - 1984		18"	18"	16"
AZTEK	2005 - 2002		24"	22"	
AZTEK	2001 - 2001		24"	24"	
BONNEVILLE	2005 - 1992		22"	22"	
BONNEVILLE	1991 - 1987		19"	19"	
BONNEVILLE	1986 - 1980		18"	18"	
FIERO	1988 - 1984		18"	18"	
FIREBIRD	2002 - 1997		24"	24"	
FIREBIRD	1993 - 1980		18"	18"	
FIREBIRD	1989 - 1982		18"	18"	18"
FIREFLY	1991 - 1989		19"	16"	16"
FIREFLY	1988 - 1985		16"	16"	16"
G5	2009 - 2007		22"	17"	
GRAND AM	2005 - 1999		22"	17"	
GRAND AM	1998 - 1985		19"	19"	
GRAND AM	1980 - 1980		18"	18"	
GRAND PRIX	2008 - 1997		22"	22"	
GRAND PRIX	1996 - 1988	FWD	20"	20"	
GRAND PRIX	1988 - 1988	RWD	18"	18"	
GRAND PRIX	1987 - 1980		18"	18"	
GTO	2006 - 2004		22"	20"	
J2000	1984 - 1982		16"	16"	16"
LEMANS	1993 - 1980		18"	18"	
MONTANA	2006 - 2001		24"	24"	16"
PARISIENNE	1986 - 1983		18"	18"	
PHOENIX	1984 - 1980		18"	18"	
SAFARI	1989 - 1987	Wagon	18"	18"	
SOLSTICE	2009 - 2006		16"	22"	
SUNBIRD	1994 - 1980		16"	16"	16"
SUNBURST	1988 - 1986		18"	18"	
SUNFIRE	2005 - 1995		22"	17"	
T1000	1987 - 1981		16"	16"	16"
TEMPEST	1991 - 1987		18"	18"	
TORRENT	2009 - 2006		24"	19"	
TRANS SPORT	1998 - 1997		24"	24"	16"
TRANS SPORT	1996 - 1990		24"	24"	13"
VIBE	2009 - 2009		26"	17"	
VIBE	2008 - 2003		21"	18"	
PORSCHE					
911	2009 - 1999		22"	22"	22"
911	1998 - 1995		15"	15"	
911	1994 - 1980		13"	13"	16"
924	1988 - 1980		18"	18"	18"
928	1995 - 1985		19"	19"	
944	1991 - 1990		19"	19"	18"
BOXSTER	2009 - 1997		22"	22"	
CARRERA GT	2005 - 2005	Single Blade	22"		
CAYMAN	2009 - 2006		22"	22"	
SAAB					

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
900	1998 - 1994	Sedan	21"	21"	20"
900	1994 - 1991	Convertible	18"	18"	
900	1993 - 1980	Sedan	16"	16"	
900	1990 - 1980	Convertible	16"	16"	
9000	1998 - 1986		21"	21"	21"
9-2X	2006 - 2005		22"	17"	15"
9-3	2007 - 2003		22"	22"	
9-3	2002 - 1999		21"	21"	20"
9-5	2007 - 1999		22"	22"	
9-7X	2009 - 2005		22"	22"	
SATURN					
ION	2007 - 2003		22"	19"	
ION-1	2005 - 2005		22"	19"	
ION-2	2007 - 2005		22"	19"	
ION-3	2007 - 2005		22"	19"	
L SERIES	2004 - 2002		19"	19"	13"
LS	2000 - 2000		19"	19"	
LS SERIES	2001 - 2001		19"	19"	
LS1	2000 - 2000		19"	19"	
LS2	2000 - 2000		19"	19"	
LW SERIES	2003 - 2001		19"	19"	
LW1	2000 - 2000		19"	19"	
LW2	2000 - 2000		19"	19"	
RELAY-1	2007 - 2007		24"	22"	16"
RELAY-2	2007 - 2005		24"	22"	16"
RELAY-3	2007 - 2005		24"	22"	16"
SC SERIES	2002 - 1991		22"	21"	15"
SKY	2009 - 2007		16"	22"	
SL SERIES	2002 - 1991		22"	21"	15"
SW SERIES	2001 - 1993		22"	21"	15"
VUE	2009 - 2008		24"	16"	
VUE	2007 - 2002		24"	19"	12"
SCION					
TC	2009 - 2005		26"	16"	
XA	2006 - 2004		24"	16"	
XB	2009 - 2008		22"	20"	
XB	2006 - 2004		20"	20"	
XD	2009 - 2008		26"	14"	
SUBARU					
BAJA	2006 - 2003		22"	20"	
DL	1989 - 1980		17"	17"	16"
FORESTER	2009 - 2009		24"	18"	
FORESTER	2008 - 2003		22"	19"	15"
FORESTER	2002 - 1998		21"	19"	15"
GL	1989 - 1980		17"	17"	16"
IMPREZA	2009 - 2008		24"	16"	
IMPREZA	2007 - 2001		22"	17"	15"
IMPREZA	2000 - 1993		21"	18"	15"
JUSTY	1995 - 1989		18"	17"	15"
LEGACY	2009 - 2005		24"	18"	
LEGACY	2004 - 2000		22"	19"	15"
LEGACY	1999 - 1995		21"	19"	16"

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
LEGACY	1994 - 1990		20"	18"	16"
LOYALE	1994 - 1990		19"	19"	16"
OUTBACK	2009 - 2005		24"	18"	
OUTBACK	2004 - 2000		22"	19"	15"
SVX	1997 - 1992		22"	20"	18"
TRIBECA	2009 - 2008		26"	20"	
SUZUKI					
AERIO	2007 - 2002		22"	18"	
EQUATOR	2009 - 2009		24"	18"	
ESTEEM	2002 - 1995		20"	18"	14"
FORENZA	2008 - 2004		22"	19"	
FORSA	1988 - 1987		17"	17"	
GRAND VITARA	2009 - 1999		19"	19"	15"
RENO	2008 - 2005		22"	19"	18"
SAMURAI	1995 - 1986		13"	13"	
SIDEKICK	1998 - 1991		17"	17"	15"
SIDEKICK	1990 - 1989		17"	17"	
SWIFT	2001 - 1995		20"	19"	
SWIFT	1994 - 1989		20"	19"	15"
SX4	2009 - 2007		26"	16"	
VERONA	2006 - 2004		22"	20"	
VITARA	2004 - 1999		19"	19"	
X-90	1998 - 1996		17"	18"	
XL-7	2009 - 2007		24"	19"	
XL-7	2006 - 2002		19"	19"	15"
TOYOTA					
4RUNNER	2009 - 2003		22"	20"	
4RUNNER	2002 - 1999		17"	17"	13"
4RUNNER	1998 - 1995		16"	16"	
AVALON	2004 - 2000		24"	17"	
AVALON	1999 - 1995		21"	19"	
CAMRY	2009 - 2007		24"	20"	
CAMRY	2006 - 2002		24"	19"	
CAMRY	2001 - 1997		21"	19"	
CAMRY	1996 - 1993		21"	19"	13"
CAMRY	1992 - 1992		18"	18"	
CAMRY	1991 - 1987		19"	17"	15"
CAMRY	1986 - 1983		19"	17"	17"
CELICA	2005 - 2000		26"	16"	20"
CELICA	1999 - 1994		21"	20"	20"
CELICA	1993 - 1986		19"	17"	19"
CELICA	1985 - 1981		17"	17"	
CELICA	1980 - 1980		17"	17"	16"
COROLLA	2009 - 2002		26"	16"	
COROLLA	2001 - 1993		20"	18"	
COROLLA	1992 - 1987		19"	17"	13"
COROLLA	1988 - 1987	FX 16	17"	17"	
COROLLA	1986 - 1983		19"	17"	17"
COROLLA	1982 - 1980		17"	17"	
CRESSIDA	1992 - 1989		20"	19"	
CRESSIDA	1988 - 1985		19"	17"	13"
CRESSIDA	1984 - 1980		17"	17"	13"

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
ECHO	2005 - 2000		22"	14"	
FJ CRUISER	2009 - 2007	2 Driver's Side Blades	16"	14"	
HIGHLANDER	2009 - 2008		26"	20"	
HIGHLANDER	2007 - 2001		22"	19"	
LAND CRUISER	2008 - 2000		24"	22"	16"
LAND CRUISER	1999 - 1998		20"	20"	16"
LAND CRUISER	1997 - 1993		18"	18"	16"
LAND CRUISER	1992 - 1990		19"	19"	15"
MATRIX	2009 - 2009		26"	16"	12"
MATRIX	2008 - 2003		21"	18"	
MR2	1995 - 1993		20"	19"	
MR2	1992 - 1991		19"	19"	
MR2	1989 - 1985		17"	17"	
MR2 SPYDER	2005 - 2000		20"	19"	
PASEO	1999 - 1992		21"	18"	
PICKUP	1995 - 1980		17"	17"	
PRIUS	2009 - 2004		26"	18"	
PRIUS	2003 - 2001		24"	17"	
RAV4	2009 - 2006		24"	16"	
RAV4	2005 - 2001		22"	19"	
RAV4	2000 - 1996		20"	18"	13"
SEQUOIA	2007 - 2001		19"	19"	14"
SIENNA	2009 - 2004		26"	19"	
SIENNA	2003 - 1998		24"	18"	17"
SOLARA	2008 - 2004		24"	19"	
SOLARA	2003 - 1999		22"	21"	
STARLET	1983 - 1981		16"	16"	15"
SUPRA	1998 - 1994		21"	19"	18"
SUPRA	1993 - 1989		19"	19"	17"
SUPRA	1988 - 1986		19"	17"	
SUPRA	1985 - 1980		17"	17"	
T100	1998 - 1993	Pick-up	19"	19"	
TACOMA	2009 - 2005		22"	21"	
TACOMA	2004 - 1999		17"	17"	
TACOMA	1998 - 1995		16"	16"	
TERCEL	1999 - 1991		18"	18"	
TERCEL	1990 - 1988		19"	17"	17"
TERCEL	1988 - 1988	Wagon	19"	17"	14"
TERCEL	1987 - 1983		17"	17"	17"
TERCEL	1987 - 1983	Wagon	17"	17"	14"
TUNDRA	2006 - 2000		19"	19"	
VAN	1989 - 1984		17"	17"	17"
VENZA	2009 - 2009		26"	22"	
YARIS	2009 - 2007		26"	14"	12"
VOLKSWAGEN					
BEETLE	2009 - 1998		21"	21"	
CABRIO	2002 - 1995		21"	19"	
CABRIOLET	1993 - 1985		16"	16"	
CORRADO	1995 - 1990		19"	19"	18"
DASHER	1981 - 1980		17"	17"	
EUROVAN	2003 - 1995		21"	21"	16"
EUROVAN	1994 - 1992		21"	21"	18"

2010 - 1980 Passenger Cars and Light Duty Trucks

Make and Model	Year	Comment	Driver	Pass.	Rear
FOX	1993 - 1987		18"	18"	18"
GOLF	2006 - 1993		21"	19"	13"
GOLF	1992 - 1985		16"	16"	16"
GTI	2006 - 2006		21"	19"	13"
JETTA	2004 - 1993		21"	19"	15"
JETTA	1992 - 1980		16"	16"	
JETTA	1992 - 1985	GLI	18"	18"	
PASSAT	2001 - 1992		21"	21"	15"
PASSAT	1991 - 1990		21"	21"	
QUANTUM	1988 - 1982		18"	18"	13"
RABBIT	1984 - 1980		16"	16"	16"
RABBIT CONVERTIBLE	1984 - 1980		16"	16"	16"
RABBIT PICKUP	1983 - 1980		16"	16"	
ROUTAN	2009 - 2009		26"	20"	
SCIROCCO	1988 - 1982		19"	19"	16"
SCIROCCO	1981 - 1981		18"	18"	16"
VANAGON	1991 - 1980		18"	18"	16"
VOLVO					
240	1993 - 1990		16"	16"	13"
242	1984 - 1980		16"	16"	13"
244	1989 - 1980		16"	16"	13"
245	1989 - 1980		16"	16"	13"
264	1982 - 1980		16"	16"	13"
265	1981 - 1980		16"	16"	13"
740	1992 - 1985		20"	20"	13"
760	1990 - 1989		21"	21"	13"
760	1988 - 1983		19"	19"	13"
780	1991 - 1988		20"	20"	
850	1997 - 1993		21"	21"	17"
940	1995 - 1991		20"	19"	13"
960	1997 - 1996		22"	22"	16"
960	1995 - 1992		21"	21"	13"
C70	2004 - 1998		21"	21"	
S40	2003 - 2000		21"	20"	16"
S60	2004 - 2001		24"	21"	
S70	2000 - 1998		21"	21"	
S80	2004 - 2004	Early Model	24"	22"	
S80	2003 - 1999		24"	22"	
S90	1998 - 1998		24"	21"	
V40	2004 - 2000		21"	20"	16"
V70	2004 - 2001		24"	22"	
V70	2000 - 1998		21"	21"	16"
V90	1998 - 1998		24"	21"	
XC70	2004 - 2003		24"	22"	
XC90	2004 - 2003		24"	22"	16"